IBO8KPRO

2026 EDITION

The Ultimate

Smart TV Setup Guide

Set up your screen, connect your devices, and solve everyday TV problems.



INDEPENDENT SMART TV GUIDANCE

IBO8KPRO.COM

Contents

Choose a chapter in this list or open the bookmarks in your PDF reader.

GET STARTED

Welcome 03

Understanding your Smart TV 04

Before you begin 05

Initial television setup 06

Connecting to your home Wi-Fi 07

Updating TV software 08

Installing official streaming apps 09

CHOOSE YOUR DEVICE

Google TV and Android TV 10

Samsung Smart TV setup 11

LG Smart TV setup 12

Amazon Fire TV configuration 13

Apple TV configuration 14

PICTURE, SOUND & DEVICES

Connecting HDMI devices 15

Understanding picture modes 16

HDR and resolution settings 17

Improving television sound 18

TROUBLESHOOT & GET HELP

Troubleshooting slow connections 19

Solving common application problems 20

Basic privacy and security 21

Quick-reference checklist 22

Official resources and support 23

New setup? Read chapters 1–7 in order. Fixing something now? Start with the quick-reference checklist on page 22.

01 / GET STARTED

Welcome

A good Smart TV setup gets you from the first power-on to a picture, sound, and connection you can depend on. This handbook gives you a short path through that work, with separate instructions for the devices that handle it differently.

WHAT TO DO

01 Start with chapters 2–7 if this is a new television. You will identify the TV, finish setup, connect it, update it, and install an official app.

02 For a new streaming box or stick, jump to the chapter for the device you actually use. A TV and a separate player can each have their own Home screen, Wi-Fi connection, updates, and app store.

03 If something stopped working, begin with the quick-reference checklist. Test one change at a time so you can see which change fixed it.

I want to…	Start with
Set up a new TV	Chapters 2–7
Connect a streaming box or soundbar	Chapters 11–13 and 16
Fix a sudden problem	Chapters 17–20

SETUP TIP

Keep your manufacturer's model-specific manual nearby. Menu names, options, account requirements, and availability vary, even among TVs released in the same year.

02 / GET STARTED

Understanding your Smart TV

A Smart TV combines a display with software that can run apps. A separate streaming player delivers its own picture and sound through an HDMI input. These are two separate systems, even when one remote controls both.

WHAT TO DO

01 Press Home on the TV remote. Look for the platform name on the Home screen or under a menu such as About or Support. Check the model number on the rear label or in your documentation if the interface is unclear.

02 Press Input or Source and select the HDMI port you use for a separate device. If the app layout changes, you are now using the external device's software.

03 Write down your TV model, external player model, and the port used by each cable. Keep this map when you need to look up instructions or diagnose a problem.

Choose the right controls



An external player sends its picture and sound through a TV HDMI input.

SETUP TIP

Use the settings on the device playing the app for app and network problems. Use the TV's settings for power, picture, inputs, and the sound sent from the TV.

03 / GET STARTED

Before you begin

Gather the items you will need before you start the on-screen setup. The first configuration is easier when you can switch between the TV, network, and account screens without stopping to look for a cable or password.

WHAT TO DO

01 Read the model's installation or quick-start guide. Use the recommended stand or mounting hardware, keep vents clear, and get a second person to help handle a large TV as directed by the manufacturer.

02 Check the remote batteries or charge level, the supplied power adapter, and the labels on your HDMI ports. Keep the TV and router readily accessible.

03 Find your home Wi-Fi name and password. For Ethernet, check whether the TV or player has a port or supports a compatible adapter.

04 Have the relevant account credentials available privately. Use account recovery on the manufacturer's or app provider's official site if you cannot sign in.

SETUP TIP

Leave the soundbar and other optional devices disconnected during the first test if the TV setup is unclear. Add each one after the TV's own Home screen and speakers are working.

04 / GET STARTED

Initial television setup

The first-run assistant usually asks about language, location, connection, and account preferences. The sequence depends on the model and can differ between the TV and a separate HDMI player.

WHAT TO DO

01 Power on the television and follow its instructions to pair or activate the remote. For a new TV in a home, choose Home mode if setup offers a choice between home and store display modes.

02 Select your display language and actual region. These settings affect app availability and certain local features. Read each permission prompt before choosing.

03 Connect the TV to your home network if you want built-in online features. Complete required account steps through the official setup flow. Some TVs offer a limited setup option for external inputs.

04 Check for software updates, then play a short video and listen through the TV speakers. If you use an antenna or separate device, verify that input afterward.

SETUP TIP

Start from the manufacturer’s recommended home picture mode, and note your current settings before experimenting.

05 / GET STARTED

Connecting to your home Wi-Fi

Wi-Fi setup joins the television or streaming device to your router. A successful connection to the router still leaves a separate question: can the router reach the internet?

WHAT TO DO

01 Open the device's network settings and choose your home network. Enter the password exactly, including uppercase letters and punctuation. Use the manufacturer's setup guide for the exact menu.

02 If your home network name never appears, test with the TV or player closer to the router when practical. A 2.4 GHz network often reaches farther, while 5 GHz can work well at closer range. Choose a network your device supports.

03 Run the device's connection check if it offers one. Open an official app and play a short video to verify actual internet access.

04 Compare a phone on the same Wi-Fi from beside the TV. If both devices fail, check the router, modem, and internet service before changing TV settings.

Follow the connection



Compare with a phone connected to the same router.

SETUP TIP

If Ethernet is supported, try a wired connection to isolate wireless problems. Keep the same TV, app, and content during the comparison.

OFFICIAL DOCUMENTATION

Samsung · Connect your TV to the internet

LG · Troubleshoot TV network issues

Roku · Connect your device to the internet

06 / GET STARTED

Updating TV software

Updates can address bugs and compatibility problems. The TV and a separate streaming player update independently, so first identify which device is having the problem.

WHAT TO DO

01 Record the current software version and exact model if you are troubleshooting. Close video playback before checking for updates.

02 On Samsung, look under Settings or All Settings, then Support and Software Update. On many recent LG webOS models, open All Settings, then Support and Software Update. Some older LG versions place update controls under About This TV.

03 Use the manufacturer's on-device updater when available. Keep power connected during the update and let the device restart on its own.

04 After the restart, confirm the reported version and retest the original issue. If the updater still fails, use the support instructions for your exact model before trying a USB update.

SETUP TIP

Use USB firmware only from the manufacturer's download page for the exact model and region, and follow its instructions for extraction and folder placement.

OFFICIAL DOCUMENTATION

Samsung · Update TV software

LG · Update your LG TV software

Google · Fix problems with your Google TV device

Apple · Apple TV support

07 / GET STARTED

Installing official streaming apps

Use the app catalog built into your TV or player. An app available on a phone or another TV platform may be unavailable for your model, software version, or region.

WHAT TO DO

01 Open your TV or player's official app catalog. Search for the service by name and review the listed app or publisher to make sure you found the right one.

02 Select Install, Get, or Add app as shown on your device. Complete any platform account requirements and wait for the app to appear on your Home screen or apps list.

03 Open the app. Follow its official sign-in instructions and review any subscription terms with that app provider. Enter activation codes only on the official site shown by the app.

04 Play a known video. If the app isn't listed, check device compatibility with its publisher or try the service on another officially supported device.

SETUP TIP

Treat a free app download and a paid service account as separate decisions. Installing the app does not automatically include a subscription.

OFFICIAL DOCUMENTATION

Samsung · Use apps on your Smart TV

LG · Install and delete TV apps

Google · Install apps on Google TV

Roku · Add apps to your streaming device

08 / CHOOSE YOUR DEVICE

Google TV and Android TV

Google TV and Android TV are related platforms with different launchers. Google TV normally offers a Home-screen app discovery area. On Android TV, the Google Play Store may be available from the apps row or menu.

WHAT TO DO

01 Follow the onscreen remote pairing prompt. Google TV may offer Google Home setup on a phone or setup with the remote. Use the options your device shows.

02 Choose your network and use your Google Account for the features you want. Some compatible TVs offer a basic setup mode with fewer smart functions.

03 On Google TV, search by app name or use the Apps tab, then choose Install. On Android TV, use the Google Play Store if your launcher exposes it. App availability varies by device.

04 If a Google TV app freezes, open Settings, then System and Restart if available. Google's guide also describes checking for system updates from System and About. Follow the TV manufacturer's menus when they differ.

SETUP TIP

If setup by phone stalls, look for the option to continue with the remote. If wireless audio or another connected accessory is involved, test the app through the TV speakers first.

OFFICIAL DOCUMENTATION

Google · Set up Google TV and its remote

Google · Install apps on Google TV

Google · Fix problems with your Google TV device

Google · Set up Android TV and its remote

Google · Android TV Help

09 / CHOOSE YOUR DEVICE

Samsung Smart TV setup

Samsung's interface and menu layout vary across model years. For current Samsung internet features, be ready to sign into a Samsung Account when required.

WHAT TO DO

01 Use the model's welcome screens to pair your remote and select the home region. To connect manually, open Settings or All Settings. In Samsung's current instructions, look for Connection, Network, and Open Network Settings. Older models may place Network under General.

02 Select Wireless or Wired as appropriate. For Wi-Fi, choose your home network and enter its password. Confirm that the TV can reach an internet service.

03 Open Home and locate Apps. Search for an available title, choose Install, and open the app to complete its own sign-in steps.

04 To check firmware, look under Support, then Software Update. If Software Update is unavailable while an app is open, return to a TV input before trying again.

SETUP TIP

If every app fails, verify connectivity before reinstalling anything. For just one failure, test another app, restart the TV, and check for app or system updates.

OFFICIAL DOCUMENTATION

Samsung · Connect your TV to the internet

Samsung · Use apps on your Smart TV

Samsung · Update TV software

10 / CHOOSE YOUR DEVICE

LG Smart TV setup

LG webOS uses Home as the starting point for apps. The network and update paths have moved between releases, so use the support instructions for the webOS version on your TV.

WHAT TO DO

01 Open Settings, then All Settings. Locate Network. LG documents different locations by model generation, including General and Connection. Choose Wi-Fi Connection and join your network.

02 Use Home to find Apps or LG Content Store, depending on your version. Search for the app, select it, and follow the on-screen prompts to install.

03 For recent webOS versions, check All Settings, Support, then Software Update. On older versions, start with General and look for About This TV if that matches LG's guide.

04 If one app fails, test a second. Confirm the TV can reach the internet, restart it, and check whether the failing app supports your TV model.

SETUP TIP

If an app is missing, check the model, region, and webOS version with the app provider. Changing the television's region can affect other services and is not a dependable compatibility fix.

OFFICIAL DOCUMENTATION

LG · Troubleshoot TV network issues

LG · Install and delete TV apps

LG · Update your LG TV software

11 / CHOOSE YOUR DEVICE

Amazon Fire TV configuration

Fire TV comes built into some televisions and is also available as separate players. Begin at the Fire TV Home screen, then follow the instructions for your exact model.

WHAT TO DO

01 For a separate Fire TV Stick, connect it to an HDMI input and power it as instructed, using the included adapter as directed. Select that HDMI input on the TV.

02 Pair the remote if prompted, choose your network, and complete Amazon account setup. Use the Fire TV Home interface to find the app you want and follow its Get or Download prompt.

03 If the player disconnects, use Fire TV Settings and Network if available. Confirm the network with a second device, then restart the player.

04 For a repeating app problem, use Fire TV Support to find your model's application management and restart instructions. Clear app data only after you know how to sign back in.

SETUP TIP

A TV USB port may not supply the power a Fire TV device needs. For unexpected reboots or power warnings, follow Amazon's model-specific power instructions.

OFFICIAL DOCUMENTATION

Amazon · Set Up Your Fire TV

Amazon · Can't connect your Fire TV device to Wi-Fi

Amazon · Fire TV Support

12 / CHOOSE YOUR DEVICE

Apple TV configuration

These instructions cover an Apple TV streaming box running tvOS. The Apple TV app on another TV is a separate product with a different setup process.

WHAT TO DO

01 Connect power and HDMI, select the matching TV input, and pair the Siri Remote when prompted. Use setup with a compatible iPhone if offered, or complete setup manually.

02 Connect over Wi-Fi or use Ethernet on a model that has the port. Complete Apple Account sign-in when needed for the features you intend to use.

03 On an Apple TV HD or Apple TV 4K, open App Store, choose a supported app, and follow its Get or purchase instructions as appropriate.

04 Open Settings, then Video and Audio, if playback has a picture or sound issue. Match Dynamic Range or Match Frame Rate may be useful, but retest the full HDMI chain after a change.

SETUP TIP

A brief black screen when switching formats can occur as the TV changes modes. A persistent blank screen calls for a direct connection to a known-good HDMI input and a compatible format.

OFFICIAL DOCUMENTATION

Apple · Set up Apple TV 4K or Apple TV HD

Apple · 4K, HDR, and Dolby Vision on Apple TV 4K

Apple · Match Dynamic Range and Frame Rate

Apple · Apple TV support

13 / PICTURE, SOUND & DEVICES

Connecting HDMI devices

HDMI carries digital picture and sound. When there is no picture, identify the source, the cable, and the exact TV input before changing advanced settings.

WHAT TO DO

01 With the equipment off, connect the source device to a TV HDMI port. Note the number on the port. For a soundbar using audio return, use the port labeled ARC or eARC on both ends as directed.

02 Power on both devices and select the matching HDMI input with the TV remote. If nothing appears, verify the source is awake and reseat the cable.

03 For a 4K HDR or high-refresh source, check support on the source, cable, TV input, and any receiver or soundbar in between. Some TVs require enabling an enhanced HDMI mode on that port.

04 Bypass intermediate equipment and connect the source directly to the TV with a compatible cable. Restore the receiver or switch only after the direct connection works.

Isolate the video path

Player or console → HDMI cable → Matching TV input

Test a direct connection before adding a receiver.

SETUP TIP

A cable or port that works at a lower output format may still fail at a higher-bandwidth format. Try the source device's automatic or conservative output setting first.

OFFICIAL DOCUMENTATION

HDMI Licensing Administrator · HDMI specifications

Apple · 4K, HDR, and Dolby Vision on Apple TV 4K

14 / PICTURE, SOUND & DEVICES

Understanding picture modes

Picture presets are starting points for different viewing conditions. A room with strong daylight calls for different choices from a dim room at night. Use content you know well to judge changes.

WHAT TO DO

01 Select the input or app you use most. Look for Picture settings and start with a neutral preset such as Standard, Cinema, or Movie, if available.

02 Tune screen light to the room. A control named Brightness may change the screen light or the level of dark tones, depending on your TV. Check your manual before making large changes.

03 For familiar movies, compare motion smoothing at its current setting and at a reduced setting. For games, try Game mode if your TV offers it and compare responsiveness.

04 Check a second input and an HDR video. Some TVs store separate settings for each source or picture format.

SETUP TIP

Use a face, a dark scene, and a bright scene to compare. If you lose shadow detail or create distracting outlines, restore the previous setting.

15 / PICTURE, SOUND & DEVICES

HDR and resolution settings

Resolution describes how many pixels form the image. HDR describes how compatible video and displays represent brightness and color. A 4K source does not automatically mean HDR, and formats such as HDR10 and Dolby Vision require their own compatibility.

WHAT TO DO

01 Identify a title and app that actually offer the format you want. Confirm your service tier, source device, display, and connection all support that format.

02 Start with the device's recommended or automatic output. On compatible external devices, try matching the source content's range or frame rate if the device offers it.

03 If the picture disappears or flickers, try a confirmed compatible HDMI port and cable, or connect the player directly to the TV. Use a stable baseline such as 1080p SDR where available.

04 Re-enable the higher resolution, HDR, or refresh rate individually. Use the TV's signal information screen, if present, to confirm what the TV is actually receiving.

SETUP TIP

If an app title advertises HDR but the TV reports SDR, check app, device and signal support before adjusting brightness.

OFFICIAL DOCUMENTATION

Apple · Match Dynamic Range and Frame Rate

HDMI Licensing Administrator · HDMI specifications

16 / PICTURE, SOUND & DEVICES

Improving television sound

Choose the intended audio output first. Sound can disappear if a TV is still sending audio to an inactive soundbar, Bluetooth device, or receiver.

WHAT TO DO

01 Check mute and volume, then play a known video. Set the TV to its internal speakers for the first test. Compare another app or input.

02 For HDMI ARC or eARC, connect between the labeled ports, select the TV audio output used by your setup, and select the matching input on the soundbar or receiver.

03 Follow the manufacturer's instructions for any required HDMI-CEC or enhanced audio settings. If playback is silent, try PCM as a diagnostic where available. Revisit surround settings after sound returns.

04 For dialogue, try a speech or clear voice mode if offered. If audio lags, check whether the TV or audio device offers synchronization before changing multiple controls.

Follow audio return

TV ARC / eARC → HDMI cable → Soundbar ARC / eARC

Set both devices to the matching output or input.

SETUP TIP

If the TV speakers work but the soundbar doesn't, narrow the problem to the external audio path, including output, input, cable, or format.

OFFICIAL DOCUMENTATION

HDMI Licensing Administrator · HDMI specifications

Apple · 4K, HDR, and Dolby Vision on Apple TV 4K

17 / TROUBLESHOOT & GET HELP

Troubleshooting slow connections

Buffering can come from weak Wi-Fi, a busy network, an internet outage, or one application. Compare devices and apps before buying equipment or resetting the TV.

WHAT TO DO

01 Play another service on the TV, then run a speed test near the TV using a phone on the same Wi-Fi. The phone result gives context. It does not directly measure the TV's connection.

02 Pause large downloads and retest. If several devices are affected, follow your network provider's directions to restart the modem and router, then let them reconnect fully.

03 If only the TV is slow, test a compatible band with stronger signal or use Ethernet if supported. Move the router into a clear position where practical.

04 Compare the results with the affected service's own guidance. If only one app is slow, check its outage status, playback settings, and device support.

What you observe	First comparison
All devices buffer	Same service on another connection, if available
Only the TV buffers	Wi-Fi versus supported Ethernet
Only one app buffers	A second official app on the same TV

SETUP TIP

Record whether the problem happens at specific hours, only in one room, or only on one app. Patterns help your internet provider or app publisher investigate.

OFFICIAL DOCUMENTATION

Google · Fix problems with your Google TV device

Amazon · Can't connect your Fire TV device to Wi-Fi

Roku · Connect your device to the internet

18 / TROUBLESHOOT & GET HELP

Solving common application problems

Start with reversible steps. Before removing an app or clearing its data, confirm you can sign back in and know whether the app stores preferences locally.

WHAT TO DO

01 Try a different title in the same app and a second app on the TV. If only one title fails, note its name and any code the app displays.

02 Close and reopen the app. Restart the TV or player from its on-screen controls if available. Run the app again before changing other settings.

03 Check the platform's system and app updates. If supported, clear the app cache before clearing app data. Use the app provider's instructions for account and playback error codes.

04 If reinstalling is supported, remove the affected app and install it again from the official store. Some preinstalled apps cannot be removed. Check model compatibility if installation fails.

SETUP TIP

Save the exact error text, app version if visible, model number, and what you already tried. Give the app publisher those details instead of sharing passwords or verification codes.

OFFICIAL DOCUMENTATION

Samsung · Use apps on your Smart TV

LG · Install and delete TV apps

Google · Fix problems with your Google TV device

Amazon · Fire TV Support

Roku · Add apps to your streaming device

19 / TROUBLESHOOT & GET HELP

Basic privacy and security

A Smart TV may offer settings for voice control, content recommendations, viewing data, or personalized advertising. The names, defaults, and effects vary by model and region.

WHAT TO DO

01 Review the privacy choices during first setup and later in the device's Settings. Use the description shown next to each option to decide which features you want to enable.

02 Apply software updates through the official updater. Use unique account passwords and enable multi-factor authentication where your platform account offers it.

03 Install apps from the device's official catalog. If an activation screen asks for sensitive information on an unfamiliar site, close it and start again from the official app or support page.

04 Before selling or giving away the device, follow the manufacturer's process to sign out, remove it from relevant account lists, and perform a factory reset.

SETUP TIP

If someone else helps with setup, enter your own credentials privately. Share the model and error code with support and keep passwords and one-time codes private.

OFFICIAL DOCUMENTATION

Samsung · Connect your TV to the internet

Google · Set up Google TV and its remote

Apple · Apple TV support

Amazon · Fire TV Support

20 / TROUBLESHOOT & GET HELP

Quick-reference checklist

Start with the symptom you can reproduce. After each check, replay the same content or repeat the same action. Keeping the test consistent helps you find the cause.

WHAT TO DO

01 Write down the device, input, app, time, and error code. Check power, mute, and input before advanced settings.

02 Try a second app, input, or cable to isolate the fault. For connection problems, compare a second device on the same network.

03 Restart the device and check for updates. Use a factory reset only after consulting support and confirming you can reconfigure the device.

Symptom	Check first	Next comparison
No internet	Correct network and password	Phone on the same Wi-Fi
No picture on HDMI	TV input and source power	Direct cable to the TV
Picture without sound	Mute and selected output	Internal speakers versus soundbar
One app crashes	Restart and update the app	Try another app or one other title
Remote doesn't respond	Batteries, charge, or pairing	Use the model's pairing guide
Update fails	Power and connection	Check model-specific support

SETUP TIP

If the TV reports a hardware fault or you see physical damage, contact the manufacturer. Keep the model and serial number available privately.

21 / TROUBLESHOOT & GET HELP

Official resources and support

Match the current document to the model and software version printed on your label or listed in Settings. Use the manufacturer for device settings, the app publisher for app accounts and playback, and your internet provider for service outages.

WHAT TO DO

01 Find the TV model and software version before searching a support site. For an external player, record the exact player model separately.

02 For picture or audio issues, include the type of content, the input number, the cable path, and whether an intermediate receiver or soundbar is involved.

03 For Roku players, follow the model's installation and activation flow, then add apps from the Roku store. Use Roku's connection help if you cannot complete setup.

04 For a correction or question about this handbook, email contact@ibo8kpro.com. Keep account credentials and payment information private.

SETUP TIP

This is an independent educational handbook. Manufacturer support resources remain the best reference for model-specific warranties, service, and supported features.

OFFICIAL DOCUMENTATION

Samsung · Connect your TV to the internet

Google · Set up Google TV and its remote

Amazon · Fire TV Support

Roku · Set up your streaming player or Streaming Stick

HDMI Licensing Administrator · HDMI specifications

LG · Troubleshoot TV network issues

Google · Set up Android TV and its remote

Apple · Apple TV support

Roku · Add apps to your streaming device